



PART #112 & #113**92-96 F-150 HOODS**

**Notice: Prefit Before Painting!
Painted or Altered Parts are Non-Refundable**

- STEP 1: Your factory hood was supplied with hinge springs, these springs hold your hood open. Our hood is much lighter. You will no longer use these springs. We supply you with a prop rod which is mounted to the passenger side radiator support. There are four bolts in a square where the radiator support meets the fender. Bolt the prop rod to the bolt furthest back and to the right.
- STEP 2: Adjust hood until proper alignment with matching panels is achieved.
- STEP 3: Adjust primary latch until it fits into the latch opening on the hood without hitting any perimeter edges of the opening. Make sure when the hood is closed you can hear the latch "click" onto the hood.
- STEP 4: After you here it click, test it to be sure it's working properly by grabbing the front edge of the hood and slowly pulling upward with a steady even pressure. If the hood opens it's not adjusted properly; repeat STEP 3 until hood cannot be pulled open after it's closed.

WARNING: MAKE SURE SAFETY CATCH IS INSTALLED & WORKING PROPERLY!

- STEP 5: Make sure the safety catch hook grabs onto its matching bracket mounted on the hood.
- STEP 6: To ensure the safety catch is working properly, close the hood, pull the hood release from inside the car and the hood will partially open. Slowly pull upward on the hood and jiggle it at the same time. If it opens without pulling the safety catch lever then it needs to be readjusted. The safety catch prevents the hood from opening in the event the primary latch fails.
- STEP 7: Locate the hood stoppers  located on each side of the radiator support. Adjust upward until they apply a small amount of pressure to the underside of the hood when it is closed. This will prevent the hood from shaking or rocking.
- STEP 8: Your original hood was supplied with a steel pop up bar  Transfer it to your Cervini hood. ***Note: use one of the bolts left over from removing your springs to install the steel pop up bar. The original one is too short.***

PART #112 & #113

QTY	DESCRIPTION	HARDWARE #
4	1/4"x20x3/4" BOLTS	92865A540
4	1/4"x20 WASHERS	90108A029
1	PROP ROD	006

