


PART # 1192 & 1196
07-09 1500 Chevy Silverado Ram Air Hood
07-09 1500 Chevy Silverado Cowl Hood

Notice: Pre fit Before Painting!
Painted or Altered Parts are Non-Refundable!

- STEP 1: Remove the striker bar and adjust the hood until proper alignment with matching panels is achieved.
- STEP 2: Reinstall the striker bar to the hood with the supplied bolts and lock washers. **Use a medium strength loctite on these bolts to keep them from backing out.**
- STEP 3: Adjust primary latch until the striker bar fits into the latch. Make sure when the hood is closed you can hear the striker bar “click” into the latch.
- STEP 4: After you here it click, test it to be sure it’s working properly by grabbing the front edge of the hood and slowly pulling upward with a steady even pressure. If the hood opens it’s not adjusted properly; repeat STEP 3 until hood cannot be pulled open after it’s closed.

WARNING: MAKE SURE THE SAFETY CATCH IS WORKING PROPERLY!

- STEP 5: To ensure the safety catch is working properly, close the hood, pull the hood release from inside the car and the hood will partially open. Slowly pull upward on the hood and jiggle it at the same time. If it opens without pulling the safety catch lever then the latch needs to be readjusted. The safety catch prevents the hood from opening in the event the primary latch fails.
- STEP 6: Locate the hood stoppers  located on the radiator support. Adjust upward until they apply a small amount of pressure to the underside of the hood when it is closed. This will prevent the hood from shaking or rocking.



PART #1192 &1196		
QTY	DESCRIPTION	HARDWARE #
4	3/4" BOLTS	13003
2	1" BOLTS	10947-01380
4	FLAT WASHERS	33004
2	LOCK WASHERS	91102A029
1	LATCH	TEM-039