

PART #373L & 373R
99-00 SNIPER-R FENDER INSTRUCTIONS

Notice: Prefit Before Painting!
Painted or Altered Parts are Non-Refundable

1. The fenders install in the factory locations. Remove the factory fenders and the side skirts.
2. Before installing fenders, pre-fit the body side molding on each fender.
3. **1** 1/4" - 20 x 3/4" bolt, **2** 1/4" washers, and **1** 1/4" - 20 nut are used to bolt the fender to the bumper.

PART #373L & 373R		
QTY	DESCRIPTION	HARDWARE #
2	HEX CAP BOLT	13003
4	WASHERS	33004
2	HEX NUT	36102
6	FLAT HEAD PHILLIPS SCREWS	WE2225
1	CIRCLE SCREEN	MEC032-P

