



## Part #7276 & #7277 (Combo Kit #8057) 13-14 Mustang GT, V6, Boss, GT/CS Billet Grilles

### Step 1 | Installing the Upper Billet Grille #7276

Mask painted area around Grille to keep the paint from scratching when removing Grille.

### Step 2

Using your finger tips, grab hold of the honeycomb design portion of the factory Grille and pop out with a quick forceful pull. This portion of the Grille is only held in with a snap fit, locking design.

### Step 3

Remove honeycomb areas from the outer bezel.

### Step 4

Remove complete front bumper from the car.

### Step 5

Place the bumper on a stand (Stand must have protection on it to keep the bumper from getting scratched or damaged).

### Step 6

Re-install the outer trim of the grille.

### Step 7

Hold the Upper Grille in place 1/8" away from touching the fog lights and center from left to right in the mouth opening.

### Step 8

Using a nail or pencil, mark the four holes that need to be drilled through the bumper cover using the pre-drilled holes in the Grille tabs as a guide. Only use an 1/8" drill bit.

### Step 9

Install the 4 screws in your hardware packet to secure the Upper Grille.

### Step 10

Re-install the bumper.

#### PART # 7276

QTY	DESCRIPTION	HARDWARE #
4	SCREWS	90935A148

#### PART #7277

QTY	DESCRIPTION	HARDWARE #
4	SCREWS	90935A148



**Step 1** **Installing the Lower Billet Grille #7277**

Hold the Grille in place centered from left to right in the Lower Grille mouth opening.

**Step 2**

Using a nail or pencil, mark the four holes that need to be drilled through the bumper cover using the pre-drilled holes in the Grille tabs as a guide. Only use a 1/8" drill bit.

**Step 3**

Install the 4 screws in your hardware packet to secure the Lower Grille.