

**KIT #8005  
(INCLUDES PART #317 AND #322)  
93-95 F-150 RAM AIR KIT**

**Notice: Painted or Altered Parts are Non-Refundable**

1. Remove the factory air box from the truck, the top half of the factory air box will become the lower half of the new ram air box.
2. Remove the threaded inserts from the factory lower half of the air box and press them into the factory top half.
3. Mount the top half of the factory air box into the fiberglass bracket with the 3 screws supplied in the hardware packet.
4. There is a 1/4" hole in the fiberglass bracket, it needs to be drilled through the air box to allow water to drain.
5. Mount the bracket and the lower half of the air box to the truck.
6. Place the air filter in the air box bottom side up, and then install the new ram air box on top.
7. Place the foam gasket on top of the air box.
8. Make all connections before starting the truck.

KIT #8005		
QTY	DESCRIPTION	HARDWARE #
3	TAP SCREWS	32144
1	FOAM GASKET	VF1331

